





SimpleCafé Frother

Use & Care Guide

Get the most from your
new Keurig® frother



Congratulations on Your New Keurig® SimpleCafé Frother



Froth milk in less than a minute.

Great coffee should be simple and convenient. Your Keurig® SimpleCafé Frother has been designed with easy-to-use settings to craft your perfect drink at home.



Scan QR code to download the Keurig® app or visit <https://www.keurig.com/hub> to access exclusive recipes for your favorite coffeehouse indulgences.




Let's Set Up

Unbox and Wash

Remove all packaging after unboxing your SimpleCafé Frother. Wash the frother cup and whisk with warm, soapy water before first use. Do not submerge frother wand in water for cleaning.*

Fully Charged is Best


We recommend **fully charging your frother prior to first use** for the best possible experience.



To charge your Keurig® SimpleCafé Frother, insert the USB-C cable (included) into the USB-C port on the frother. Plug the cable into a 5V power adapter (not included).

The back part of the frother will display blinking LEDs, and all 3 LEDs will illuminate when fully charged and ready to use.

NOTE: A fully depleted battery can take up to 3 hours to fully charge.



Assemble Frother Wand


Insert the whisk and push firmly into the frother wand base until it cannot be pushed further.



Assemble Frother Wand Into Frother Cup

Firmly insert the frother wand into the frother cup lid to attach the frother wand into the frother cup.

Your Keurig® SimpleCafé Frother is now ready to use!




***IMPORTANT: The frother wand is not dishwasher safe. Do not submerge frother wand in water for cleaning.** Wipe clean and only use nonabrasive cleaning materials to prevent damage to your frother wand. Dry with soft cloth after cleaning.

For ease of cleaning, the removable whisk, lid, and frother cup are top-rack dishwasher safe. Frother cup is microwave safe.

Get to Know Your SimpleCafé Frother

SimpleCafé Frother Wand's Multiple Settings

Your Keurig® SimpleCafé Frother wand has 3 preprogrammed settings (Latte, Cappuccino, and Manual) to create your perfect beverage.



Designed to create the best foam for lattes and cappuccinos, the frother wand will automatically aerate the milk for a nice foamy result.

SimpleCafé Latte and Cappuccino are automatic settings. Frother will automatically stop when frothing is complete or can be manually stopped by pressing and holding the power button as needed.

The Manual setting allows for extra customization, since froth quality varies depending on milk temperature and milk type. Toggle down to Manual setting to

start Manual mode. Once you have reached your desired froth consistency, just press the button once again to turn the frother off.




DO NOT
PUT IN
DISHWASHER



DO NOT
MICROWAVE

SimpleCafé Frother Cup

Your Keurig® SimpleCafé Frother cup is microwave safe and has special markings to indicate the right amount of milk to use.



For a perfect latte or cappuccino, fill up to the latte or cappuccino line.

The frother cup also has cup measurement and ounce lines for customizing beverages to your own liking. Just fill the frother cup with your milk of choice.

For ease of cleaning, the lid, frother cup, and silicone grip are top-rack dishwasher safe. Do not put wand in the dishwasher.




TOP-RACK
DISHWASHER
SAFE



SimpleCafé Frother

- A. Frother Wand
- B. Removable Whisk
- C. Lid
- D. Frother Cup
- E. Sleeve



Milk and Coffee Recipes Guide

Keurig® SimpleCafé Frother is designed to work with the most common milk type — whole milk. For best results with other dairy and dairy alternatives, please use Manual mode for additional frothing time, as they may require more aeration.


Use the provided milk fill lines on the SimpleCafé Frother cup for the best froth results.

PRO TIP:

- If using a mug and not the provided frother cup, never fill more than one-third of the mug with milk.

Depending on the type of milk, it can more than double its volume.

- The Manual setting provides a higher-speed aeration if you want thicker froth. This setting is also recommended when frothing dairy alternatives.



COFFEE AND MILK RATIO SUGGESTION

Different types of milk produce different results. Depending on which milk you use, here's what you can expect.

Fat-Free/Skim Milk: Easy to froth; it creates a light, airy foam.

2% Milk: Easy to foam like skim milk, but with a creamier consistency.

Whole Milk: Higher fat content creates the richest-tasting foam.

Dairy Alternatives: Results will vary depending on type; loses bubbles more quickly than dairy milk. Use frother Manual setting for best results.


Lactose-Free Milk: Results will vary due to its different properties.

Not All Brands Are the Same


Even individual brands of milk can froth differently, so experiment with different brands to see what works best.

Let's Make Your Favorite Drinks at Home

Let's make a HOT LATTE

-  1 Use a 12oz mug and brew your coffee using the smallest brew size available. Then set the coffee aside while you froth the milk.
-  2 Fill frother cup with preferred milk to Latte line.*
-  3 Warm milk of your choice up to 160 degrees Fahrenheit in microwave. Due to different types of microwaves, this will typically take 1-2 minutes.
-  4 Cover the frother cup with the provided lid and insert frother wand securely.
-  5 Press the power button to toggle to Latte. The frother will automatically start.
-  6 Frothing is complete when the Latte light is no longer illuminated.
-  7 Pour frothed milk over coffee and spoon some froth on top.

Let's make a HOT CAPPUCCINO

-  1 Use a 12oz mug and brew your coffee using the smallest brew size available. Then set the coffee aside while you froth the milk.
-  2 Fill frother cup with preferred milk to Cappuccino line.*
-  3 Warm milk of your choice up to 160 degrees Fahrenheit in microwave. Due to different types of microwaves, this will typically take 1-2 minutes.
-  4 Cover the frother cup with the provided lid and insert frother wand securely.
-  5 Press the power button to toggle to Cappuccino. The frother will automatically start.
-  6 Frothing is complete when the Cappuccino light is no longer illuminated.
-  7 Pour frothed milk over coffee and spoon some froth on top.

Prefer cold drinks? Skip heating the milk. Brew your coffee and let it cool or add ice.



***NOTE:** Frothed milk expands. Use frother cup fill lines. If frothing in a mug instead of the frother cup, do not overfill the mug.

NOTE: Do not put frother wand or whisk in the microwave.

Charging

For the best frothing experience, ensure that your frother has sufficient battery power before frothing.

One LED light will indicate it's almost time to charge your frother. Your SimpleCafé frothing wand front panel will also display blinking lights to remind you that it is time to recharge.



To charge your Keurig® SimpleCafé Frother, insert the USB-C cable (included) into the USB-C port on the frother. Plug the cable into a 5V power adapter (not included).

To prolong the life of the battery, be sure not to overcharge; Keurig® SimpleCafé Frother should fully recharge after 3 hours. Ambient (room) temperature range recommended for charging system during charging.

Caring for Your Frother

Wash the frother cup and whisk with warm, soapy water before first use.

- 1. Whisk, lid, and frother cup are top-rack dishwasher safe. You can also rinse the metal whisk under running water.
 - 2. **The frother wand is not dishwasher safe. Do not submerge frother wand in water for cleaning.** Wipe clean and only use nonabrasive cleaning materials to prevent damage to your frother wand.
 - 3. Dry with soft cloth after cleaning.
- Do not put the frother wand in the microwave.**

Click or Call!

Have Questions?

We're here to help. Visit support.keurig.com for step-by-step videos on cleaning, descaling, and more.



Still Need Help?

Give us a call at
1-866-901-BREW (2739).

Troubleshooting

ISSUE	POSSIBLE CAUSE(S)	SOLUTION
The frother whisk is shaking too much when in use.	The whisk is not fully inserted.	Ensure the whisk is properly inserted into the wand.
	The whisk is damaged.	Inspect if the whisk is damaged or bent. For any manufacturing-related issues, call Keurig consumer care, 1-866-901-BREW (2739). Spare parts are also sold at keurig.com.
Frother isn't starting. or The frother mode/power button is not functional or is unresponsive.	The frother needs to be recharged.	Charge the frother with the provided cable.
	Power-off protection triggered.	Ensure the frother is not used to stir or mix heavy, thick liquid.
	The frother wand is damaged.	For any manufacturing-related issues, call Keurig consumer care, 1-866-901-BREW (2739). Spare parts are also sold at keurig.com.
Insufficient foam/froth. or Froth time is longer than expected to achieve the desired milk foam.	The whisk is not fully inserted.	Ensure the whisk is properly inserted into the wand.
	The frother wand is not installed into the frother cup lid properly.	Remove and reinstall the frother wand into the frother cup lid. Ensure the frother is snug and perpendicular to the lid.
	The whisk is damaged.	Inspect if the whisk is damaged or bent. For any manufacturing-related issues, call Keurig consumer care, 1-866-901-BREW (2739). Spare parts are also sold at keurig.com.

Warranty

LIMITED ONE-YEAR WARRANTY

Keurig Green Mountain, Inc. ("Keurig") warrants that your SimpleCafé Frother will be free of defects in materials or workmanship under normal home use for one year from the date of purchase. Keurig will, at its option, replace a defective frother without charge upon receipt of proof of the date of purchase. If a replacement frother is sent, a new limited one-year warranty will be applied to the replacement frother. This warranty only applies to SimpleCafé Frothers operated in the United States and Canada. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state and, in the case of Canada, from province to province. Any damage to or malfunction of your SimpleCafé Frother resulting from the use of non-Keurig® accessories may not be covered by this warranty.

WHAT IS NOT COVERED BY THE LIMITED WARRANTY?

THIS WARRANTY DOES NOT COVER CONSEQUENTIAL OR INCIDENTAL DAMAGES SUCH AS PROPERTY DAMAGE AND DOES NOT COVER INCIDENTAL COSTS AND EXPENSES RESULTING FROM ANY BREACH OF THIS WARRANTY, EVEN IF FORESEEABLE. Some states or provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you depending on the state or province of purchase. Nor does this warranty cover damages caused by use of non-Keurig® accessories, use of parts other than genuine Keurig® parts, or external causes such as abuse, misuse, inappropriate power supply, or acts of God.

OTHER LIMITATIONS

THIS WARRANTY IS EXCLUSIVE AND IS IN LIEU OF ANY OTHER EXPRESS WARRANTY, WHETHER WRITTEN OR ORAL. IN ADDITION, KEURIG HEREBY SPECIFICALLY DISCLAIMS ALL OTHER WARRANTIES WITH RESPECT TO YOUR KEURIG® SIMPLECAFÉ FROTHER, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. Some states or provinces do not allow disclaimers of such implied warranties or limitations on how long an implied warranty lasts, so the above limitation may not apply to you depending on the state or the province of purchase.

HOW DO YOU OBTAIN WARRANTY ASSISTANCE?

Please call Keurig Customer Service at our toll-free phone number, 1-866-901-BREW (2739). Canadian Customer Service can be reached at 1-800-361-5628. Please do not return your frother without first speaking to Keurig Customer Service to obtain a Return Materials Authorization (RMA) number. Keurig® SimpleCafé Frothers returned without an RMA number will be returned to the sender.

Coffeehouse taste in your own home.

FIND YOUR PERFECT POD

With over 75 brands and hundreds
of varieties, find your match at

[keurig.com/new](https://www.Keurig.com/new)